

# #736 MONITOR



## PARTS LIST

| ITEM NO. | PARTS NO. | DESCRIPTION     | QUANTITY |
|----------|-----------|-----------------|----------|
| 1        | B0471     | DISCHARGE ELBOW | 1        |
| 2        | B0515     | HANDLE          | 1        |
| 3        | F0251     | HANDLE BALL     | 1        |
| 4        | B0485     | FLANGE          | 1        |
| 5        | F0072     | BALL BEARINGS   | 104      |
| 6        | O0460     | O-RING          | 2        |
| 7        | B0490     | BRAKE SPINDLE   | 2        |
| 8        | B0510     | BRAKE NUT       | 2        |
| 9        | F0250     | BRAKE BALL      | 2        |
| 10       | B0850     | BRAKE SHAFT     | 2        |
| 11       | B0491     | HEX. NUT        | 2        |
| 12       | F0160     | ROLL PIN        | 2        |
| 13       | B0450     | SWIVEL JOINT    | 2        |
| 14       | B0470     | INLET ELBOW     | 1        |
| 15       | B0451     | SWIVEL JOINT    | 1        |
| 16       | B0460     | ADAPTER         | 1        |
| 17       | F0201     | GREASE FITTINGS | 2        |
| 18       | S0070     | SCREW           | 4        |
| 19       | B0449     | SWIVEL JOINT    | 1        |
| 20       | B0462     | STOP BRACKET    | 1        |
| 21       | F0247     | NUT             | 1        |
| 22       | S0067     | SCREW           | 2        |
| 23       | B0463     | NUT             | 1        |